



CRAG™ Filtration Media

CRAG™ is compatible with all processing solvents. Suggested for in-line CRC applications or filter cake applications where granular alumina is used. Suggested applications include, column chromatography, in-line CRC, and filter cake applications where clarification, light winterization, or light drying properties are desired. Suggested amount has no upper limit.

Safety

SDS Sheets: Available upon request on all chemicals used in this process.

Preparation

Required Materials:

CRAG™ Filtration Aid, Winterization Aid

In-line Filtration Housing

Procedure

1. Load filter media into filtration housing or solution.
2. Ensure that media is secured in filtration housing.
 - a. 1 micron mesh screen works well to secure filtration media.
3. CRAG™ does not need to be wetted prior to use.
4. Run filtration using polar or non-polar solvent.
 - a. Avoid saturation and maintain flow.
5. Follow disposal instructions in SDS.

Contact info@mediabros.store for additional information and questions.